


- 1-17: anti-reverse lever
- 1-18: spring
- 1-19: lever
- 1-20: spring
- 1-21: bushing
- 1-22: ball bearing
- 1-23: washer
- 1-24: fix plate
- 1-25: screw
- 1-26: main shaft
- 1-27: one way clutch
- 1-28: pinion gear
- 1-29: ball bearing
- 2-1: rotor
- 2-2: screw
- 2-3: bail arm cover

- 1-1: main body
- 1-2: rear cover
- 1-3: rear cover screw
- 1-4: screw
- 1-5: side cover
- 1-6: screw
- 1-7: main cover
- 1-8: ball bearing
- 1-9: washer
- 1-10: main gear
- 1-11: ball bearing
- 1-12: shaft
- 1-13: screw
- 1-14: slider
- 1-15: drive gear
- 1-16: screw

EXPLODED DRAWING



- 1-1: main body
- 1-2: rear cover
- 1-3: rear cover screw
- 1-4: screw
- 1-5: side cover
- 1-6: screw
- 1-7: main cover
- 1-8: ball bearing
- 1-9: washer
- 1-10: main gear
- 1-11: ball bearing
- 1-12: shaft
- 1-13: screw
- 1-14: slider
- 1-15: drive gear
- 1-16: screw

- 1-17: anti-reverse lever
- 1-18: spring
- 1-19: lever
- 1-20: spring
- 1-21: bushing
- 1-22: ball bearing
- 1-23: washer
- 1-24: fix plate
- 1-25: screw
- 1-26: main shaft
- 1-27: one way clutch
- 1-28: pinion gear
- 1-29: ball bearing
- 2-1: rotor
- 2-2: screw
- 2-3: bail arm cover

- 2-4: screw
- 2-5: bail arm
- 2-6: bail line
- 2-7: bail line system
- 2-8: drag button
- 2-9: spool
- 2-10: washer
- 2-11: click plate
- 2-12: shaft
- 2-13: click seat
- 2-14: nut
- 2-15: screw
- 2-16: fix plate
- 2-17: line guard
- 2-18: ball bearing
- 2-19: line roller

- 2-20: ball bearing
- 2-21: washer
- 2-22: bail arm
- 2-23: screw
- 2-24: bail arm cover
- 2-25: screw
- 2-26: screw
- 2-27: screw
- 2-28: rotor cover
- 2-29: bail trip shaft
- 2-30: bail trip shaft
- 2-31: spring
- 3-1: handle assembly
- 3-2: handle cover
- 3-3: washer

□